

EcoSphere® LED Base Instructions

The LED Base is primarily used for darker locations with minimal overhead or ambient light). Please see www.eco-sphere.com for further information. The LED Base is powered by the included power supply or by 3 AAA batteries (not included).

CONTENTS

- LED Base
- 4.5V power supply
- Power cord
- Instruction sheet

SAFETY WARNINGS & PRECAUTIONS

- NEVER look directly at the LEDs.
- Not required for EcoSphere® health.
- Do not let the EcoSphere fall or get bumped off of the LED base.
- Do not leave the LEDs on for an extended period of time. Doing so may cause excess algae growth.
- Not intended for use by children.
- Not a source of heat.
- For indoor use only.
- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Remove batteries when product is stored for a long period of time or when batteries are exhausted.
- Dispose of exhausted batteries properly.
- Only the recommended batteries should be used.
- Keep all batteries away from children.
- Batteries must be inserted with correct polarity.

INSTRUCTIONS

1. Unpack contents
2. LED must be turned off before plugging in (see illustration).
3. Place LED base on flat, level surface.
4. Plug the power cord into the power supply.
5. Plug the power supply into a suitable wall outlet. Plug the power cord into the LED base.
6. Place your EcoSphere® directly on the center of the LED base. Take care that the EcoSphere does not fall or get bumped off of the base.
7. Turn the LED base on using the On/Off switch. NEVER look directly at the LEDs.
8. The LED base defaults to slow color pulse mode. Press the Mode button again to select a solid color (red, white, blue, or green). From solid green mode, press the Mode button again to return to slow pulse mode, or press the Mode button 5 times to get to fast pulse mode.
9. Press the Mode button again to turn the LED base off, or use the On/Off switch.

